

Programming Instructions

1. Create process plan.
2. Check model to drawing as drawing is the authority. Modify model if needed to match the drawing.
3. Program Corner Clamp Left Hand (LH).
4. Mirror Corner Clamp LH for the Corner Clamp Right Hand (RH).
5. Program Edge Clamp.
6. Create tool list(s) and setup sheet(s) for each part.