

Instructions

Performance Process

1. Create process plan.
2. Check each model to drawing as drawing is the authority. Modify models if needed to match the drawings.
3. Program Corner Clamp LH (Left Hand).
4. Mirror Corner Clamp LH for the Corner Clamp RH (Right Hand).
5. Program Edge Clamp.
6. Create tool list(s) and setup sheet(s) for each part.